


Steel Diamond


No Dig Fencing System








No Dig Fencing System - Install




Panel ring rests on top of stake sleeve Bottom gate hinge rests on top of base panel ring




Panel Width

Continue adding panels, using the panel to mark the position of the next stake






No Dig Fencing System - Gate Latch Operation



No Dig Fencing System - Gate Adjustment





Questions, problems, missing parts? Before returning to your retailer, call our customer service department at 800.607.6409, 8:00 am – 5:00 pm EST Monday – Friday. Or eMail us at CustomerService@OPBglobal.com